





CORREDERAS

CIERRE SUAVE ACERO INOX H45

Guía de Instalación


Formato sin escala

4505SS



CODE/ CÓDIGO	A	B	C	D	E	F	G	H	
4505SS300	11-13/16" / 300mm	11-13/16" / 300mm	3-3/4" / 96mm	3-7/16" / 87mm	5-5/16" / 135mm	7-11/16" / 195mm	-	10-3/16" / 258mm	15
4505SS350	13-3/4" / 350mm	13-3/4" / 350mm	3-3/4" / 96mm	3-7/16" / 87mm	5-1/4" / 134mm	7-11/16" / 196mm	-	12-3/16" / 309mm	15
4505SS400	15-3/2" / 400mm	15-3/2" / 400mm	5-1/16" / 128mm	3-7/16" / 87mm	5-1/4" / 134mm	7-13/16" / 198mm	11-5/8" / 295mm	14-5/16" / 364mm	15
4505SS450	17-11/16" / 450mm	17-11/16" / 450mm	6-5/16" / 160mm	3-7/16" / 88mm	5-3/8" / 136mm	7-7/8" / 200mm	13-9/16" / 345mm	16-1/8" / 409mm	15
4505SS500	19-11/16" / 500mm	19-11/16" / 500mm	7-9/16" / 192mm	3-9/16" / 91mm	5-1/2" / 139mm	8" / 203mm	14-1/4" / 362mm	17-15/16" / 455mm	15
4505SS550	21-5/8" / 550mm	21-5/8" / 550mm	8-13/16" / 224mm	3-13/16" / 97mm	5-7/8" / 150mm	8-7/16" / 214mm	17-9/16" / 446mm	20-1/16" / 510mm	15

Space requirement/ Requerimiento de espacio



Installation dimensions/ Dimensiones de instalación (mm)

